

1. Remove the Ovation SaniStation from the carton and stand upright.



2. Unlock the sanitiser storage compartment at the rear of the stand with the key supplied.



3. Remove the lid from the sanitiser bottle and drill or cut a 7mmØ hole for the flexible tube to allow it to remain inserted into the bottle.



4. Slide the tube into the bottle and screw the lid back on the bottle and lock the compartment shut.



5. Secure the supplied anti-bacterial drip tray with the screws provided using a Phillips head screwdriver.



6. The gel should self-prime so keep pressing the pedal until the dispenser squirts the first portion of sanitiser gel into your hands.



7. Your Ovation SaniStation is now ready for use.



8. Follow the same process when installing a replacement bottle of sanitiser gel or repeat step 4, step 6 and step 7 when refilling the existing 5.0L bottle.